


The first active heating exchanger for refitting from ATEC-eMAX





**Maximum
input of flue
temperature
is 280°C**

**output of flue
temperature
can be 50°C;
maximum
120°C**